

IMPORTANT INFORMATION

IMPORTANT! Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Always stake or weight down your E-Z UP® shelter. Do not use in any potentially windy or rainy weather. Wind and rain can damage the E-Z UP® shelter and may also result in injury to you or others. Therefore, do not rely on shelter for protection in heavy or prolonged rain storms.
- The E-Z UP® shelter is designed as a temporary sun shelter. Do not leave up for extended periods.
- Use caution when handling the E-Z UP® frame. Avoid pinching hands or fingers as frame opens or closes.
- Do not use shelter in a lightning storm.
- Do not leave your E-Z UP® Instant Shelter® product unattended.
- Do not build fires under shelter.

WARNING: Keep all flame and heat sources away from this top fabric. This top meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the top may render the flame-resistant properties ineffective.

CARE AND MAINTENANCE

For long lasting durability and the best possible protection for your E-Z UP® Instant Shelter® product, follow these E-Z care and maintenance instructions:

- Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the E-Z UP® top and frame dry completely before closing or storing to avoid mildew. Inner legs must be dry and clean before sliding inside outer legs.
- Frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before applying top.
- Use a seam sealer if top leaks or drips water. Available at most sporting goods and hardware stores.
- Slightly tighten bolts if frame becomes loose.

For online warranty, service, parts and accessories as E-Z as 1-2-click, contact us at

www.ezupdirect.com

Ask about our other E-Z UP® Instant Products™



1 YEAR LIMITED WARRANTY

INTERNATIONAL E-Z UP, INC., manufacturer of the E-Z UP® Instant Shelter® product, warrants to the original purchaser who provides a dated sales receipt from an Authorized Dealer, each part of the E-Z UP® shelter to be free from defects in material or workmanship for a period of one year after the date of original purchase. The E-Z UP® Instant Shelter® frame is covered under a limited one year warranty and guarantees the frame to be free from defects in material or workmanship. This warranty applies only for normal and expected uses, as determined by the manufacturer.

INTERNATIONAL E-Z UP, INC.'s obligation and liability under this warranty is limited to the repair or replacement (at its option) of the product or its parts, after its own review and examination.

RETURN ADVISORY - Before returning any part or product to INTERNATIONAL E-Z UP, INC. or its designated representative, please phone or write to obtain specific return shipping instructions. All shipping costs must be prepaid, and INTERNATIONAL E-Z UP, INC. is not responsible for products damaged in transit.

CONDITIONS - This warranty shall be void as to any product which has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberate damage of the product, nor to use of the product that does not conform with the product instructions.

This warranty is provided in lieu of all other warranties, expressed or implied.

We Make Life E-Z!™

INTERNATIONAL E-Z UP, INC.

1601 Iowa Avenue, Riverside, California 92507

(909) 426-0060 • Fax (909) 426-0063

www.ezupdirect.com

Customer Service Hot Line

1 (800) SHADE ME

7 4 2 3 3 6 3

OWNER'S MANUAL

E-Z UP® INSTANT SHELTER® PRODUCT



"Sets Up in Seconds!"

SPRINT®

10ft x 10ft (3.0m x 3.0m)

Take time to learn how to provide years of durable and safe use from your E-Z UP® Instant Shelter® product. After reading these instructions carefully, if you have any need of assistance, call our Customer Service Department.



Customer Service Hot Line

1 (800) SHADE ME


7 4 2 3 3 6 3

www.ezupdirect.com

- Sprint® Frame
- Polyester Top with Silver UV Backing
- 4 Piece Stake Kit
- Carry Bag

FIRST TIME TOP ATTACHMENT

Please read each step before you attempt to set up. Save these instructions for future reference.



1. Place your E-Z UP® frame in the center of area to be shaded. With partner on opposite side, grasp outer legs, lift off the ground, and step backwards - stopping at full arms length, approximate size as shown above.




2. Gently unfold the fabric top and place it over the open frame.




3. Attach the fabric top to the E-Z UP® frame by matching hook & loop strips on the top with the hook & loop strips on the frame. Pull the corners down fully.



1. Place your E-Z UP® frame in the center of area to be shaded. With partner on opposite side, grasp outer legs, lift off the ground, and step backwards - stopping at full arms length.



2. Grasp the top and bottom of diamond-shaped area of trusses by "open" sticker. Slightly lift shelter up and push hands together while stepping backwards until shelter is fully opened. **Be careful not to pinch fingers or push too hard so as to avoid truss damage.**




3. Engage Pull Pin slider at each corner by pushing up on slider with one hand while holding down on top of leg with other hand. Pull Pin will engage in hole. Repeat step on remaining legs.




4. With partner, lift two adjacent outer legs up and slide out the inner legs until the snap button locks. Repeat on the opposite legs - make sure to do two legs at a time on same side.



1. With partner, slightly lift up two adjacent outer legs, depress snap button and slide inner legs into outer legs. Repeat on the opposite legs - making sure to do two legs at a time on same side.



2. Release the Pull Pin slider at each corner by first lifting fabric top corner and pull the pin out to release.



3. With partner on opposite side, grasp top and bottom of diamond-shaped area of trusses by "close" sticker and slightly lift up. Shake shelter slightly, pulling hands apart, while stepping towards partner until shelter is 3/4 closed. **Be careful not to pinch fingers!**



4. With partner grasp two outer legs and push frame together to fully close it. **Be careful not to pinch fingers!** Store shelter in roller bag. (See Roller Bag Instruction enclosed within your Warranty Kit).